

1) PREPARE





PRE-COLOUR



Keeps the grain visible

Emphasizes the natural grain for a more attractive look.



Intense colours

Penetrates deep into the wood. Gives the wood a beautiful, coloured surface. Provides more intense colours than oil.



Simple application

Easy and fast to apply with a WOCA Applicator.



Can be used with all WOCA oils

Pre-Colour cannot be used alone as it only provides colour to the wood, and not protection.



PRODUCT DESCRIPTION

Pre-Colour is a water-based stain for unfinished and sanded interior wood surfaces, such as floors, stairs, furniture and panels. The stain colours the wood and enhances the natural wood grain.

APPLICATION AREA

For staining untreated, new, or newly sanded wooden surfaces. Ideal for all types of wood.

Product information

Coverage: 8-10 m²/L Packaging: 2.5 L

Colours: White, Grey, Black and Brown





WORK DESCRIPTION

Preparation

Product, room and floor temperature must be between 15-25°C. Wood humidity must not exceed 12%. Ensure good ventilation during application and when drying.

The wood must be newly sanded, use grit 100-120 for the final sanding. Vacuum thoroughly. Clean the wood with WOCA Intensive Wood Cleaner and leave it to dry for at least 8 hours before applying the stain.



TREATMENT

- 1 Thoroughly shake the container of Pre-Colour, both before and during use. Containers with different batch numbers should be mixed to avoid colour mismatch.
- Apply an even coat of undiluted stain along the wood grain with WOCA Applicator. Please note: Pre-Colour can also be polished into the wood to achieve a more even colouring. Use at least 1 L of Pre-Colour per 10 m². On vertically mounted wood, apply from top to bottom. Leave the surface to dry for 8-12 hours
- 3 Sand with a green pad to obtain a smooth surface and vacuum thoroughly.
- The surface must be finished using one of WOCA's oils, following the product instructions.