



1 PREPARE 2 TREAT 3 MAINTAIN

# EXTERIOR WOOD PRIMER



wood

## For highly absorbent wood

Protects the wood against moisture. Reduces cracking in the wood. Extends the lifetime of the wood.



effect

## High efficiency

Improves the adhesion and durability of the product that goes on top of it. Helps minimizing stains from bleeding through.



application

## Easy to apply

Easy and fast to apply with a brush or roller. Water-based.



treatment

## For pre-treatment

Requires additional treatment with oil.



## PRODUCT DESCRIPTION

Exterior Wood Primer is a water-based primer for priming surfaces such as façades, windows, fences and carports. The product protects the wood, as well as enhancing adhesion and durability of a subsequent surface treatment. Exterior Wood Primer is very well suited for fir, accoya, larch, pine, oak and pressure-impregnated wood.

## APPLICATION AREA

For new and old wood. Very well suited for fir, accoya, larch, pine, oak and pressure impregnated wood.

### Product information

Coverage: 8-10 m<sup>2</sup>/L

Packaging: 2.5L



## WORK DESCRIPTION

### Preparation

Clean the surface with WOCA Exterior Wood Cleaner. The surface must be completely dry and free of dust and dirt. New wood should be treated as soon as possible. Can also be used as a pre-treatment for previously oiled wood that has been weathered.

The treatment with Exterior Wood Primer must be performed in dry weather, at a temperature between 15-30° C. Avoid direct sunlight and intense heat. Wood humidity must not exceed 17%.

### Note

Exterior Wood Primer is a pre-treatment product, so the surface must then be treated with WOCA Exterior Wood Oil within 14 days. Make sure that you have properly sealed the container after use. Check the treated surfaces annually. Repair any damage immediately.

Optimum durability is achieved by regular cleaning and correct treatment, depending on the construction, the condition of the wood and wind and weather.



### TREATMENT

- 1 Shake the container well.
- 2 Apply Exterior Wood Primer undiluted, with a brush or roller. It is important that the product is applied thoroughly and evenly. Start with the end sections of the wood.
- 3 Leave the wood to dry for at least 24 hours before treatment.