

Bona Fiber Pad

Technical data sheet

Bona Fiber Pad for effective polish removal on wood and resilient flooring prior to recoating. Can also be used dry on raw wood for a light brushing effect. Particularly suitable for brushing pine flooring and other soft wood floors. Available in various sizes to reach all parts of the floor. Its open fiber structure makes it easy to clean and use anew.

- Extremely dimensionally stable and long lasting
- Extremely long lifetime
- Minimize the risk of varying sheens
- Usable with handheld machines
- Good dust extraction due to open fiber structure

Technical data

Composition:	Special Fiber Material
Diameters:	407mm, 150mm, 180mm
Thickness:	10 mm
Backing:	The 150 and 180 mm discs have velcro backing. The 407 mm is a double sided disc.
Packaging:	1 pc per box

Technical info

The extremely long lifetime of the Bona Fiber Pad means the same disc(s) can be used on the entire surface with the same efficiency, creating a consistent sanding and consequently a consistent surface sheen.

For a seamless transition to the edges of the room, use the 150 mm disc with Velcro attached to a SupraFlex.

Polish removal

For cleaning the centre of the room use the 407 mm disc together with Bona FlexiSand or similar single disc machine (max 150 rpm). For edges use the 150 mm discs. Always use the discs wet, in water or a cleaning solution.

Rinse the disc(s) occasionally during use to ensure continued performance in case polish is clogging the disc.

Wood floor brushing

Bona Fiber Pad can be used on all types of wood suitable for brushing such as oak, ash, pine, spruce. Softer species such as pine and spruce get a deep brushing with the Fiber Pad. Harder species such as oak and ash only get a light brushing. Wood brushing with the Fiber Pad should always be made dry. Best and more efficient results are achieved by using the 150 mm Fiber Pads attached to a Bona PowerDrive and a Bona FlexiSand (no extra weights) but also the 407 mm disc can be used for single disc machines.

1. Sand the floor in several steps up to grit 100-120 ensuring a smooth, even and scratch free surface, removing all parts of any old coating.
2. Brush the floor with the Bona Fiber Pad(s) placed underneath the Bona FlexiSand or another single disc machine.
3. For reaching all the way up to the wall, use 150 mm pads attached to a Bona Supraflex.
4. Make a quick and light sanding across the whole surface using a grit 120 abrasive to ensure consistency between edge and centre room sanding.
5. Carefully remove all sanding dust before surface treating.

Important! Never use Bona Fiber Pads for intermediate sanding and/or on coated surfaces.

Sanding



Bona[®]