



1 PREPARE 2 TREAT 3 MAINTAIN

INTENSIVE WOOD CLEANER

PRODUCT DESCRIPTION

Intensive Wood Cleaner is a specially developed cleaning product for all indoor wood surfaces, such as furniture, doors, panels, kitchen worktops etc. regardless of whether they are untreated, oiled or lacquered. Intensive Wood Cleaner effectively cleans

and removes dirt, grease and stains, quickly and easily.

APPLICATION AREA

Cleaning of new, untreated, sanded and treated wood. Ideal for all species of wood.



Easy and fast cleaning

Basic cleaning and grease removal. Prepares surfaces for additional treatment. Reduces the surface tensions, so the following treatment can be done with great result.



High efficiency

Neutralizes tannin and helps minimize the risk of discoloration. Helps achieve more intense colours. Extends the lifetime of the wood.



Easy to use

Ready-mixed. Handy and practical spray that simplifies the use of the product. For all surfaces.



Indoor climate labelled

Ensures a good working environment during application. Does not harm indoor air quality. Only for indoor use.

Product information
Packaging: 750 ml
Colours: Colourless





WORK DESCRIPTION

Preparation


Use WOCA Wood Stain Remover for particularly stubborn stains.

Please note

Intensive Wood Cleaner leaves oiled and wax-treated surfaces completely free of oils, so re-oiling/waxing after cleaning is required. Lacquered surfaces should be refreshed with WOCA Master Care.



APPLICATION



WIPING OFF

TREATMENT

- 1 Shake the bottle thoroughly before use.
- 2 Spray Intensive Wood Cleaner onto the surface.
- 3 Allow the mixture to work for 5 minutes, before wiping down with clean water.
- 4 Leave the surface to dry for 2-8 hours, depending on subsequent treatments.